Inputs

Resource	Function	Details
Analog 1	Sensors and inputs/TPS, PPS/TPS/Main signal input	TPS Main
Analog 2	Sensors and inputs/TPS, PPS/TPS/Check signal input	TPS Check
Analog 3	Sensors and inputs/Pressure/Parameters/Fuel pressure sensor input	Fuel Pressure
Analog 5	Sensors and inputs/Pressure/Parameters/AC pressure sensor input	AC Pressure
Analog 6	Fn 3	Oil Pressure Switch

Outputs

Resource	Function	Details
Injector 1	Fueling/Injectors/Injectors phase/Cylinder 1	
Injector 2	Fueling/Injectors/Injectors phase/Cylinder 2	
Injector 3	Fueling/Injectors/Injectors phase/Cylinder 3	
Injector 4	Fueling/Injectors/Injectors phase/Cylinder 4	
Injector 5	Fueling/Injectors/Injectors phase/Cylinder 5	
Injector 6	Fn 1	Starter Relay
Auxiliary 1	Outputs/Coolant fan/Output	Coolant Fan
Auxiliary 2	Fn 2	Gear Lock
Auxiliary 3	Boost/Parameters/Output	Boost Solenoid
Auxiliary 4	Outputs/Fuel pump/Parameters/Output	Fuel Pump
Auxiliary 5	VVT/CAM 1/Parameters/Solenoid output 1	VVT Intake
Auxiliary 6	VVT/CAM 2/Parameters/Solenoid output 1	VVT Exhaust
H-bridge 1A	DBW/Parameters/Enable	DBW Motor +
H-bridge 1B	DBW/Parameters/Enable	DBW Motor -
H-bridge 2A	Outputs/AC clutch/Clutch output	AC Clutch
H-bridge 2B	Outputs/Main relay/Main relay output	Main Relay
Ignition 1	Ignition/Coils/Ignition outputs/Cylinder 1	
Ignition 2	Ignition/Coils/Ignition outputs/Cylinder 2	
Ignition 3	Ignition/Coils/Ignition outputs/Cylinder 3	
Ignition 4	Ignition/Coils/Ignition outputs/Cylinder 4	
Ignition 5	Ignition/Coils/Ignition outputs/Cylinder 5	