


BLACK CONNECTOR

1	EGT in #1	9	EGT in #2	17	Ecu Ground
2	Knock Sensor in #1	10	Knock Sensor in #2	18	Sensor Ground
3	Analog In #2	11	Analog In #3	19	Analog In #4
4	CLT In	12	TPS In	20	Analog In #1
5	WBO Vs	13	WBO Ip	21	IAT In
6	Camsync In #2	14	VSS In	22	WBO Vs/Ip
7	Primary trigger	15	Camsync In #1	23	+5V supply
8	Ignition coil #5	16	Ignition coil #4	24	Power Ground

GREY CONNECTOR

1	Ignition coil #6	9	Ignition coil #3	17	Power Ground
2	Stepper motor #1 (A)	10	Stepper motor #1 (B)	18	Power +12V
3	Stepper motor #2 (A)	11	Stepper motor #2 (B)	19	WBO Heater
4	AUX 6	12	AUX 5	20	AUX 4 / Tacho
5	AUX 3	13	AUX 2	21	AUX 1
6	Injector #4	14	Injector #5	22	Injector #6
7	Injector #1	15	Injector #2	23	Injector #3
8	Ignition coil #1	16	Ignition coil #2	24	Power Ground

HOW TO READ:



BOSCH LSU 4,2

1	WBO Vs
2	WBO Rcal
3	WBO Heater +12V (fused)
4	WBO Heater
5	WBO Vs/lp
6	WBO lp

